Keyboard (shortcuts)

View control	
Shortcut	**Function**
Zoom	Ctrl + Mouse Wheel Right Mouse Button + Mouse Wheel
Zoom In	Ctrl + "+", "="
Zoom Out	Ctrl + "-"
1:1	Ctrl + "0"
Fit	
Fill	
Pan	Middle Mouse Button + Drag, Shift + Right Mouse Button + Drag Shift + Arrow Keys (not implemented yet)
Reset pan	Ctrl + Shift + "0"

Application Main Menu	
Data load/save	
Shortcut	**Function**
Ctrl + **O**	Load data
Ctrl + **S**	Save data
View	
Shortcut	**Function**
Alt + **Enter** / **F11**	Toggle On / Off Fullscreen
Escape	Leave Fulscreen Mode
Shift + **F1**	Show Only Main View
Shift + **F2**	Show Two Views
Shift + **F3**	Show Three Views
Shift + **F4**	Show Four Views
Shift + **F5**	Show / Hide Left Panel
Shift + **F6**	Show / Hide Right Panel
Ctrl + **G**	Show Grid
Ctrl + **Shift** + **G**	Toggle Next Grid Info
Alt + **S**	Stereo On / Off
Alt + **L**	Only Left Camera
Alt + **R**	Only Right Camera
Alt + **I**	Invert Cameras
Alt + **T**	Image Fit Mode On / Off
P	Play / Pause
Shift + **Tab**	Toggle Display Panels
Ctrl + **Alt** + **C**	Color Mode (only for color cameras)
Ctrl + **Alt** + **M**	Mix Grayscale Mode (only for color cameras)
Ctrl + **Alt** + **R**	Red Channel Grayscale Mode (only for color cameras)

Ctrl + **Alt** + **G**	Green Channel Grayscale Mode (only for color cameras)
Ctrl + **Alt** + **B**	Blue Channel Grayscale Mode (only for color cameras)
	DM
Shortcut	**Function**
C	Connect to the Hardware
H	Toggle On / Off Enhancing
	Controllers
Shortcut	**Function**
Q / **A**	Aperture Increase / Decrease
W / **S**	Exposure Increase / Decrease
E / **D**	Gain Increase / Decrease
+ / **-**	Zoom In / Out
Alt + **+** / **Alt** + **-**	Zoom In / Out Predefined
Alt + **0**	Auto Zoom Step
Alt + **1**	Zoom 1x Step
Alt + **2**	Zoom 2x Step
Alt + **3**	Zoom 5x Step
Alt + **4**	Zoom 7x Step
Alt + **5**	Zoom 10x Step
F	Next Predefined Focus Step
Ctrl + **0**	Auto Focus Step
Ctrl + **1**	Focus Step 5 µm
Ctrl + **2**	Focus Step 10 µm
Ctrl + **3**	Focus Step 50 µm
Ctrl + **4**	Focus Step 100 µm
Ctrl + **5**	Focus Step 500 µm
Ctrl + **J**	Toggle On / Off Joystick
Ctrl + **Alt** + **0**	Set Default Joystick Navigation Settings
Ctrl + **Alt** + **1**	Lock/Unlock Dominant Joystick Axis
Ctrl + **Alt** + **2**	Lock/Unlock Offset Joystick Axes
Ctrl + **Alt** + **3**	Lock/Unlock Rotate Joystick Axes
Ctrl + **Alt** + **4**	Lock/Unlock Rotation Center
	Recording Data
Shortcut	**Function**
R	Start / Stop Movie Recording
Ctrl + **P**	Take Photo
Ctrl + **Shift** + **P**	Show Take Photo Dialog
	HDR / Tonemapping
Shortcut	**Function**
Space	Toggle Fast / Slow Tonemapping
Ctrl + **F1**	Set 8-bit Tonemapping Mode

Ctrl + **F2**	Set 16-bit Tonemapping Mode

Calibration	
Shortcut	**Function**
F5	Toggle Left Camera Horizontal Flip
Ctrl + **F5**	Toggle Left Camera Vertical Flip
F6	Toggle Right Camera Horizontal Flip
Ctrl + **F6**	Toggle Right Camera Vertical Flip
Shift + **Left** / **Shift** + **Right**	Horizontal Shift Increase / Decrease
Shift + **Up** / **Shift** + **Down**	Vertical Shift Increase / Decrease
Ctrl + **Left** / **Crtl** + **Right**	Angle Z Increase / Decrease

3D-Ruler Tool	
Shortcut	**Function**
Ctrl + **N**	Take New Snapshot for Marking Points
Delete	Clear Ruler
F4	Toggle Sync Moving of Pivots
Ctrl	Hide Ruler
Shift	Hide Pivot Squares

Whitebalance Panel	
Shortcut	**Function**
F2	Rename Selected Whitebalance Preset
Delete	Delete Selected Whitebalance Preset

Video Emulator	
Shortcut	**Function**
Right	Next Movie Frame
Left	Previous Movie Frame
Home	Go To Begin Movie
End	Go To End Movie