

# Setting glue line

## Proper Alignment of the Glue Line During 3D Model Registration

During the 3D model registration stage, it is crucial to correctly specify the position of the glue line. There are two main scenarios:

1. The Stone is Glued as Originally Planned in the HPC Project

- In this case, the glue line should be set exactly as shown in the HPC plan.
- The current slide demonstrates how the glue line should be aligned in such a scenario.

### Glue point aware recognition

> 50% height visible above glue is what we recommend

can work for less you may try and study what is the limit

2. The Gluing Point Differs from the HPC Project

- If the actual glueing point does not match the initial HPC plan, follow this recommendation:

### Basic recognition

Use small amount of glue

Glue in flat zone to have good separation (ex: CVD cube side)

In this case you may glue as you like, NOT AS suggested by glue point and recognition will work