

# Automatic Actions

This group of settings is related to the automatic actions that may or may not be performed after scanning (see [Scanning](#) ).


Settings are available on Settings > General Settings > Automatic Actions section. Settings ar split into two tabs:

On this page:

1 [Post-scan Actions](#)

2 [Post-scan Export](#)

## Post-scan Actions



Option	Meaning	Default state
Align first facet to door	Aligns the real stone so that the model's first facet is turned to the door, in order to facilitate marking.	Off
Generate reports	<p>Generates the selected reports. Note that this setting is made for each cutting type separately. For each selected report, select the template, color, and action (wherever applicable).</p> <p>The choice of possible actions depends on the report type:</p> <ul style="list-style-type: none"><li>Polish reports can be either printed or opened in MS Word.</li><li>Export report can only be saved.</li><li>Label report can only be printed.</li><li>Standard report can only be viewed in its panel (see <a href="#">Standard Report</a> ).</li></ul>	Off

## Post-scan Export

Settings

Page Filter

General

Scanning

Automatic Actions

Reports

Automatic Actions

Post-Scan Actions

Post-Scan Export

Full project export

☐ OXGZ
 Exported models location: C:\Users\neretin\Documents\OctoNus Software\Exported Models\OXGZ
 

Browse...

Active model export in basis

Basis:

☒ Report
 ☐ Scanner

Export formats:

☐ ASCII
 Exported models location: C:\Users\neretin\Documents\OctoNus Software\Exported Models\ASCII
 

Browse...

☐ STL text
 Exported models location: C:\Users\neretin\Documents\OctoNus Software\Exported Models\STL\_TEXT
 

Browse...

☐ STL binary
 Exported models location: C:\Users\neretin\Documents\OctoNus Software\Exported Models\STL\_BINARY
 

Browse...

☐ DMC
 Exported models location: C:\Users\neretin\Documents\OctoNus Software\Exported Models\DMC
 

Browse...

☐ GEM
 Exported models location: C:\Users\neretin\Documents\OctoNus Software\Exported Models\GEM
 

Browse...

Option	Meaning	Default state
Full project export	Exports the whole project (including the scanned model and contours) in an *.oxgz format (HPOxygen's native format). The user is prompted to choose the location for the exported file.	Off
Export	<p>Exports the scanned model in a variety of formats (see <a href="#">Export model</a> ). The user is prompted to choose the basis (Report or Scanner) and the location for the exported file.</p> <p>The available formats are:</p> <ul style="list-style-type: none"> <li>• ASCII</li> <li>• STL (text)</li> <li>• STL (binary)</li> <li>• DMC</li> <li>• GEM</li> </ul>	Off