

Calibration

What needs to be calibrated?

- 1. For all DALSes
 - a. [Calibration of a Zoom Encoder](#)
- 2. DALS Stereo
 - a. [Calibration of stereo disparity](#)
- 3. DALS with color cameras
 - a. [Calibration of white balance](#)
- 4. DALS connected to autostereoscopic display:
 - a. [Setup autostereoscopic display](#)

System	Cameras	3d display	Calibration of a Zoom Encoder	Calibration of white balance	Calibration of stereo disparity	Setup autostereoscopic display
DALS	1 BW	no	+			
DALS+ (manual Z)	1 RGB	no	+	+		
DALS++ (motorized Z)	2 BW	no	+		+	
	2 BW	autostereoscopic	+		+	+
	2 RGB	no	+	+	+	
	2 RGB	autostereoscopic	+	+	+	+

'+' in the table below means the need of calibration.