

How to Get Started

When you first started to use Stereo Movie Viewer

Step-by-step guide

1. Check your hardware compatibility ([system requirements](#)):
 - a. [Workstation configuration](#)
2. [Enable NVIDIA 3D Vision](#)
3. Configure your system for stereo (depending on your hardware):
 - a. [NVIDIA Quadro + 3D TV](#)
 - b. [NVIDIA GeForce + 3D TV](#)
 - c. [NVIDIA Quadro + 3D Vision Ready display](#)
 - d. [NVIDIA Quadro + Half-mirror multi-display system](#)
4. Download and install the latest version of the Stereo Movie Viewer
5. Please read the [quick guide](#) before using the application

Related articles

- [How to Get Started](#)
- [How to Enable Windowed Stereo for NVIDIA Quadro \(active shutter glasses\)](#)
- [How to Enable NVIDIA 3D Vision Stereo](#)
- [How to Enable Half-Mirror Multi-Display Systems \(polarized glasses\)](#)
- [How to Connect PC with NVIDIA Quadro to 3D TV](#)
- [How to Connect PC with NVIDIA GeForce to Samsung 3D TV](#)
- [3D Smart TV not entering 3D mode when connected to NVIDIA GeForce or Quadro with 3DTV Play](#)
- [NVIDIA 3D Vision Stereo not working after graphics drivers update](#)