# 2019-10-23 - HPOxygen Server 5.3.42

Here you can find information about what is new in HPOxygen Server version 5.3.42.

#### On this page:

1 Inclusions - Grey Status 2 Solutions Report
3 Customizing Profiles - Improvements
4 Managing Allocation Forms
5 SweetLine Improvement
6 New Smart Recut Parameters
7 Client Versions Integration - Multi-Diamond Algorithms Enabled
8 Fixed Unknown Cut Grade Because of Girdle Value
9 Fixed Problems and Improvements

# Inclusions - Grey Status

Now you are able to set Grey Status for inclusions of your model. Inclusions having this status will not be taken into account during allocation.



# Solutions Report

The system now allows comparing solutions using Solutions Report. This report allows comparing solutions by main parameters including ASET and Office pictures.

⊗ Oxygen - [Demo1ct.oxg] ■ File Fdit Virw Inclusion Window Settinas Help				- 🗆 X
Scon Rectt dumonds indications (%) + DEZ G11 G2 ** **		$\left. \left. \left. \left  \begin{array}{c} \bigcirc \  \   \overline{m}_1 \end{array} \right  {\color{black} \overline{m}_2} \hspace{.1cm} {$		
Allocation solutions ×				×
			Sort by Price 🕙 🗸 🕯	• view
		N 14	N H	Model
# Cutting Price Mass Alloc Yield Jarit 12 m Gr Cut Syn			읖 ×	I3D Mini View
Imported model     Initize     Initiz	Solution number	7	9	Comparative I3D Mini View
4 • Brillant 7333\$ 1.0033 SR 98.11% VS1 H EX EX EX	Weight, ct	1.0025	1.0002	Solutions Report
□ 7 4 • Brillant 7333\$   1.0025 SR 98.11% VS1 H EX EX EX	Drice f	7222	7333	Excelutore
3 • Brillant 7333\$ 1.0014 SR 98.11% VS1 H EX EX EX	Price, 3	7555	1355	racecivare
▼ 9 ♣ Brillant 7333\$ 1.0002 SR 98.11% VS1 H EX EX EX				Standard Report
6 Brillant 5792\$ 0.9951 SR 97.13% VS1 H EX EX EX				My Appraiser
2 • Brillant 5733\$ 0 0.9815 96.15% VS1 H EX EX EX	ASET			▼ Reports
🗌 10 🔹 Brillant 4889\$ 🛑 1.0026 SR 98.11% VS1 H EX-FR EX-VG EX-FR				Poich Papart
		Chinese and Chines		Custom Report
		A T A	N T	Comparative Report
		S0 2	SO Y	Disktabel
4	- 17			Princ Laber 58
Diamond Info	Office			Export Report Data
<ul> <li>Inclusions (0)</li> </ul>				Export Model
Appraiser and Pricelist		A CARLON AND A CAR		✓ Model Building Info
Annraker: MvRound   GIA Faretware + MvRound	Cutting	Brilliant	Brilliant	
Profile: MvRound Profile1   Show Editor	(i) Vield %	98.11	98.11	
Pricelist: LEXUS PRICE 09MARCH 2012		2011	2011	
	Clarity	VS1	VS1	
Diamond Allocation	Color	н	н	
Algorithm: 13. SmartRecut (Brillant, Oval)	Optical symmetry	_	-	
Fix Girdle Cut grade: EX *	Final grade	EX	EX	
Fix Crown Fix Pavilon Symmetry grade: EX	Cut grade	EX	EX	
	Symmetry grade	EX	EX	
Start Allocation	Brightness	-	-	
			,	Show Model

#### To use the feature:

- In the Solution List, select solutions to be included in the Solutions Report, then click
  On the right panel, click Solutions Report. The report is displayed in the Scene.
  Note If you include many solutions in the scene the line to the scene.
- - Note If you include many solutions in the report they can be displayed not all at once, but on different pages
  - Page switcher and the **Columns per page** setting are displayed in the bottom of the report page
- You can sort the solutions in the report using the Sort by control.
- You can add or remove solutions from a report via the Solution List using the context menu.
- You can remove a solution from the report by clicking (do not confuse with vich removes the solution from report and **deletes** from the Solution List)
  When deleting a solution from the list, it is deleted from the report as well.
- You can add/remove all solutions at once. To do so, in the Solution List, click the arrow 🕶 to the right of 🙅 or 💩, then from the displayed menu, select Add All Solutions to Solutions Report or Remove All Solutions from Solutions Report correspondingly.

# **Customizing Profiles - Improvements**

In HP Oxygen, each profile consists of cutting parameter intervals and Smart Recut presets values. The system allows copying both cutting parameter intervals and presets values into your own editable profile - there you can further tune them.

Now copying intervals and preset values is improved. You can:

- Duplicate existing profile into yours in one click (all tabs, all parameters, both intervals, and preset values)
- Quickly compare your profile with any other both intervals and preset values
- Load intervals for all parameters (all tabs!) in one click
- Load intervals only, presets only, or both intervals and presets in one click
- Load presets values for all presets or only for one preset

ppraiser Editor										×														
						GI	A Facetware +	MyRound															Hide	2
						Profi	le: MyRound_	Profile1 🏼															Prese	ets
Cut Symmetry Other																								
Parameter	[ FR	[ GD	[ VG	[ EX	EX ]	VG ]	GD ]	FR ]	1.Ult	aSym	2.Hig	hSym	.Mediu	ımSyr	I.Norm	nalSyn	5.Sta	ndard	6.Lov	vSym	Extend	edLim	8.Max	Mass
Table 🚯	10	46,5	49,5	51,5	62,4	66,5	69,5	99	1	0,9	1	1	1	1	1	1	1	1	1	1	1	1	100	100
CrownAngle 🚯	10	21,75	26,25	31,25	36,75	38,75	40,25	90	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
PavilionAngle 🚯	10	38,7	39,7	40,5	41,9	42,5	43,1	90	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
SweetLine	-9	-6	-3	-1,5	1,5	3	6	9	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
StarLength 🚯	10	32,5	37,5	42,5	57,5	72,5	Current	90	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
LowerGirdleLength	50	57,5	62,5	75	80	92,5	Difference +4.	5 99	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
GirdleBezel 🚯	0	1,25	1,75	2,25	4,75	5,75	7,25	20	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
GirdleValley 🕂 🛛 🚯	0	0	0,35	0,75	2,94	4,14	6,14	20	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
CrownHeight 🚯	5	10,5	12	12,3	17	17,5	18,5	40	1	1	1	1	1	1	1	1	1	1	1	1	100	100	100	100
TotalHeight 🚯	10	54	57	58	64,5	66	70	90	1	1	1	1	1	1	1	1	1	1	1	1	100	100	100	100
Culet 🚯	0	0	0	0	0,2	1,5	2	20	-	0,5	-	1	-	1	-	1	-	1	-	1	-	1	-	100
CrownPainting 🚯	-9	-6	-3	-2,5	2,5	5	7	20	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
PavilionPainting 🚯	-9	-5	-3	-2,5	2,5	4	6	20	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
SumPainting 🚯	-9	-6	-5	-3,5	5	8	10	20	1	1	1	1	1	1	1	1	1	1	1	1	1	1	100	100
GirdleVerticality	-20	-1,5	-1	-0,5	0,5	1	1,5	20	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
HeightGirdleExtraFacet 🛛 🚯	0	0	0	0	2	4	8	20	-	0,5	-	0,6	-	0,6	-	0,6	-	0,8	-	0,8	-	1	-	1
GirdleCrownExtraFacets	0	0	0	0	0	2	4	20	-	1	-	1	-	1	-	1	-	1	-	1	-	1	-	1
GirdlePavilionExtraFacets	0	0	0	0	3	4	6	20	-	1	-	1	-	1	-	1	-	1	-	1	-	1	-	1
GirdleExtraFacets 🚯	0	0	0	0	2	4	8	20	-	1	-	1	-	1	-	1	-	1	-	1	-	1	-	1
Import Show difference	from: MyRour	H <u>_</u> HA ▼							Show o	lifferen	ce from	MyRo	und_H4	•						Unsav	ed Ch	anges	Duplie	cate
Export  Load profile Load profi								presets	<b>,</b> •					4	0 6	D	iscard		Appl	y	prof	ile 🕴		

Below is a brief description of how to work with the new features:

- You can only modify editable profiles, so first go to one of them under your appraiser.
- Click Show Presets, if necessary.
- To compare your profile to another one, in Intervals and/or Presets sections, select value in Show difference from. Mouse over the highlighted differences to see details.
- To select parameter click it. Use the context menu to select all.
- To deselect parameter, click it again. Use the context menu to deselect all.
- For selected parameters, use the context menu to load Intervals from, Presets from or Intervals and Presets from.
  Unsaved changed values are highlighted with bold. Unsaved changes notification is displayed.
- To save changes, click Apply. Applying saves on all tabs. Applying intervals also saves presets, but not vise versa.
- To load intervals for all parameters (all tabs), in the Intervals section, use Load Profile.
- To load preset values for all parameters (all tabs), in the Presets section, use Load Presets. Use All presets or select the preset to load.
- To load an entire profile (all parameters and preset values on all tabs), use **Duplicate Profile**. Changes are automatically applied immediately.
  You can **Discard** unsaved changes. Discarding erases changes on all tabs, for intervals and presets separately.
- You can at any moment step-by-step Undo or Redo or Redo your changes. Works both for saved and unsaved.
  You can copy and paste values, using CTRL-C, CTRL-V or the context menu.
  You can rename your editable profiles.

### Managing Allocation Forms

Now you can manage allocation forms of your registered cuttings in the solution list.

⊗ Oxygen - [Oxygen3]	
File Edit View Inclusion Window Settings Help	
Scan Recut diamonds inclusions (%) * DZ G1 G2 * Scan Scan Galanad Gala	g 🛞 🖤 🛞 📥 📕 I   ⊕ ++   ♡ 🖙 m₁ m₂ m₄ vs ℘ ℘ ≤ ↔ ↔ + འ
Allocation solutions	x
▼ Plans & Scans	
🚖 🚖 📕 🗦 📕 📕 📕 🗮 🗙 🗛 🕶 Compare Standa	ard Report
# Cutting Price A Mass Alloc Yield Jarib )Z rm- G	Gr Cut Jym
✓ 1 ● MyOval_01 10600\$ 0 1.0587 Forms 0.00% VS1 H E	ex ex myAr
2 • MyOval_01 (MyOval_01_1) 7637\$ 1.7247 Forms 0.00% VS1 H E	EX EX MyAn
✓ 3 ● MyOval_01 (MyOval_01_2) 7235\$ ● 1.6813 Forms 0.00% VS1 H E	EX EX MyAr
Image: A state of the state	
Diamond Info	
<ul> <li>Inclusions (0)</li> </ul>	
✓ Appraiser and Pricelist	
Appraiser: MyAnyCutOpt   MyAnyCutRelative	
Profile: MyAnyCutRelative_1	Show Editor
Pricelist: LEXUS_PRICE_09MARCH_2012	
Algorithm: 18. Semipolished 💌 🗆 + 9	Smart Recut
Cutting list: Client cuttings • 1/3 O	and grade:
Show Allocation forms in solution list	·
C4 ASC MyOval 01 PearSample1	
	Allocation

How you can manage the allocation forms:

- You can use empty project via File > New. This will provide you with an empty solution list.
  Or add your allocation forms to solution list of any opened project.
  To show allocation forms, select your cutting, then right-click it and select Show allocation forms in solution list. If your cutting has allocation forms, they will be copied to the solution list.
- You can use all tools of the system, available for usual solutions, to analyze characteristics of your allocation forms.
- Note Your displayed forms are copies. If you make some changes to them, this will not affect the initial copies actually assigned to the cutting. Still, you are able to register changed copy as the additional form for the same cutting.
- In the solution list, from the contextual menu, you can:
  - Remove from allocation forms... This is the only operation affecting not only the copy but also the source.
  - Add as allocation form to another cutting...
- Register as new cutting...
  If necessary, you can save you displayed copies of allocation forms as a separate project.

### SweetLine Improvement

As the result of additional research, for the SweetLine parameter, the slope of the optimal line is changed from "negative 1:4,5" to "negative 1:4



Detailed information about using the SweetLine parameter is presented in the video below:

Video   SweetLine - Time-Savin	Video   SweetLine - Time-Saving Approach to Getting Better Optical Performance										
Published:	2019, October 1	Last Updated:	2019, December 5	v.2.0							
Your browser does not support the HTML5 video element											
Video summary:											
CrownAngle = 34.5 and Pav     Brilliants belonging to axis g     The SweetLine parameter s     There are two ways of using     Video keywords: SweetLine, Sw	<ul> <li>CrownAngle = 34.5 and PavilionAngle = 40.75 named <i>Tolkowsky Point</i> provide the best optical performance</li> <li>Brilliants belonging to axis going through Tolkowsky Point with the negative slope 1:6 also provide excellent optical performance</li> <li>The SweetLine parameter sticks solutions to this axis</li> <li>There are two ways of using SweetLine: via SweetLine profile or using your own editable profile with SweetLine, CrownAngle and PavilionAngle set to your needs</li> </ul>										
Published in:	Release Notes	2019-10-23 - HPOxygen Server 5.3	3.42								
	Documentation Using SweetLine										
	Playlists All Videos										
	Also As Separate Page   Specification										

# New Smart Recut Parameters

The new parameters have been added to the appraisers used by the Smart Recut algorithms:

(i) This parameter is applicable to the following cuts: AnyCut (only when performing SmarRecut via Relative appraiser).

#### Defines how much (in %) the angle between normals of any neighboring facets can deviate after Smart Recut comparing to Recut.

If at least one of the neighboring facets is girdle or culet, the limitation is not applied. The girdle shape is controlled by the Girdle Shape Tolerance parameters. The culet is not taken into account.



#### Calculation

The parameter is set manually via preset and control the rule:

#### A(1+min/100) < B < A(1+max/100)

#### Where:

- A the angle between normals of neighboring facets after Recut
- B the angle between normals of neighboring facets after Smart Recut
- min a left boundary in preset, should always be negative, for example, "-25"
- max a right boundary in preset

#### Usage and Examples

If the parameter set to "-25, 50" and the angle between normals of neighboring facets after Recut (A) is "10°" then:

- 10(1-0.25) < **B** < 10(1+0.5)
- 7.5 < **B** < 15
- the angle between normals of the same facets after Smart Recut (B) should be within the interval from 7,5° to 15°.

#### Reporting

Reported in	Section	Values	Units	Bookmarks	Name in Reports		
None	NA	Single value	% from the initial angle	NA	NA		

#### Visualization in Appraisers

Value	Units	Bookmark	Tab	Parameter Name	Comment
Single value	% from the initial angle	NA	Cut	AdjacentFacetsAnglesEveryTolerance, %	Visible only when presets are displayed.

(1) This parameter is applicable to the following cuts: AnyCut (only when performing SmarRecut via Relative appraiser).

Sets limitation "not less than this value" for the angle between normals of any neighboring facets.

# If at least one of the neighboring facets is girdle or culet, the limitation is not applied. The girdle shape is controlled by the Girdle Shape Tolerance parameters. The culet is not taken into account.



#### Calculation

The parameter is set manually via preset.

#### Usage and Examples

Should be used to avoid transforming the neighboring facets into a single plane.

#### The current default values are:

Appraise	er Editor																		x
				My Profile:	/AnyC Defa	utRela ult (r	<b>ative</b> ead on	ıly)										Hide Prese	e ets
Cut	Symmetry	Other																	
Param	neter			.AllNa	arrowed	ertices	Narrov	nglesi	Varrow	irdleN	larrow	Girdle\	Viden	۱ngles	Widen	ertices	Wider	3.AIIW	idenec
Adjace	entFacetsAngl	esEveryM	in, °	1	-	0,7	-	1	-	0,7	-	0,7	-	0,5	-	0,7	-	0,5	-

#### Reporting

Reported in	Section	Values	Units	Bookmarks	Name in Reports		
None	NA	Single value	o	NA	NA		

#### Visualization in Appraisers

Value	Units	Bookmark	Tab	Parameter Name	Comment
Single value	0	NA	Cut	AdjacentFacetsAnglesEveryMin	Visible only when presets are displayed.

# Client Versions Integration - Multi-Diamond Algorithms Enabled

As part of the integration of the different Oxygen client versions, the algorithms producing multi-diamond solutions are enabled in the system and now available in the Algorithm list.

### Fixed Unknown Cut Grade Because of Girdle Value

The calculation error leading to a negative girdle and thus unknown cut grade has been fixed.

#### From: Utpal Mistry

Dear Sergey

Attached project shows negative girdle due to new GIA rule. which gives unknown cut grade.

--Attached:



For the presented example and similar cases, the girdle height now will be "0".

### Fixed Problems and Improvements

The following fixes for the known problems and improvements have been implemented:

- For the SmartRecut algorithm:
  - the bugs for specific examples have been fixed
- minor improvements have been made
- For the "MyRound | GIA Facetware + MyRound" appraiser, "MyRound\_H&A" profile, the presets have been improved to provide the better spectrum of solutions
  In the Scene, the model basis was broken in some cases after using I3D Mini View the error leading to this wrong behavior has been fixed