

Solutions Report

The *Solutions Report* allows comparing solutions by main parameters including ASET and Office pictures. This report is displayed in the system itself - in the Scene.

The screenshot shows the Oxygen software interface. The 'Plans & Scans' panel on the left lists various diamond solutions with columns for mass, allocation, yield, and cut. The central report table displays two columns of solutions, with rows for ASET and Office views. The 'View' panel on the right shows the 'Solutions Report' option selected. The 'Sort by' dropdown in the report table is set to 'Price'.

Solution number	7	9
Weight, ct	1.0025	1.0002
Price, \$	7333	7333
ASET		
Office		
Cutting	Brilliant	Brilliant
Yield, %	98.11	98.11
Clarity	VS1	VS1
Color	H	H
Optical symmetry	—	—
Final grade	EX	EX
Cut grade	EX	EX
Symmetry grade	EX	EX
Brightness	—	—

To use the feature:

- In the Solution List, select solutions to be included in the Solutions Report, then click . The included solutions are marked with the symbol.
- On the right panel, click **Solutions Report**. The report is displayed in the Scene.
 - Note** If you include many solutions in the report they can be displayed not all at once, but on different pages
 - Page switcher and the **Columns per page** setting are displayed in the bottom of the report page
- You can sort the solutions in the report using the **Sort by** control.
- You can add or remove solutions from a report via the Solution List using the context menu.
- You can remove a solution from the report by clicking (do not confuse with which removes the solution from report and **deletes** from the Solution List)
- When deleting a solution from the list, it is deleted from the report as well.
- You can add/remove all solutions at once. To do so, in the Solution List, click the arrow to the right of or , then from the displayed menu, select **Add All Solutions to Solutions Report** or **Remove All Solutions from Solutions Report** correspondingly.