# **Reflect Scan**

() To use this feature, you must have the appropriate hardware: Helium Crown Reflect and Helium Pavilion Reflect scanners.

Reflect Scan is a technology that uses reflection imaging to achieve greater precision than the one provided by the Shadow Scan. Reflect scanning requires two separate hardware pieces and two stages of operation:

On this page:		
1 Pavilion Scanning 2 Crown Scanning		

## **Pavilion Scanning**

To run the shadow scanning of the whole stone and the reflect scanning of the pavilion, perform the following steps:

Mount the stone in the Heliu Start HP Carbon. Use the scan mode. On the left panel, in the Cutt	im Pavilion F	d section	anner. , do one	of the fc	llowing:				
<ul> <li>a. select the appropria</li> <li>b. expand the list, the</li> </ul>	n, use of the s	e from the samples f	e predef rom the	Sample	s section	or click		to load	a new sa
Scan Recut diamonds inplaished Photoreal developer colors	galahad galahad compass	añoj 📗 🥪 🖤			Standard				
	Stillert     Per       Balant     Step Cu       Cylinder     Asian St	Oral Oral Emeral Ary Cut	Marquite Curbino Polyhedron	Rest Frest Proces Roging	Brilart       Brilart       Brilart       Cyinder	Pear Dear Step Cut Adam Star	Oral Oral Eneral Any Cut	Require Cushon Poish Polyhedron	Heart Heart Pricess Polyhedron
17 sec									

(i) A sample can be loaded from a file (\*.dmc, \*.mme, or \*.gem). Once loaded, it remains in your list of models (see Models management ) under the name Sample.

5. Under Precision, select the desired precision. HPCarbon stores the most recent precision setting for each particular cutting type separately. The stored precision setting is applied automatically whenever the cutting type selection is changed. In a typical workflow, it is recommended to scan round brilliants with 400 contours and Princess cuts with 800 contours since the latter cutting contains more facets with a nearly similar orientation which requires higher precision to resolve.



Note that you may also enter a custom number of contours. This requires switching the panel to Advanced mode with the dropdown switch down below:

✓ Cutting	& Method			
	$\bigcirc$	$\bigcirc$	$\bigcirc$	
Brilliant	Pear	Oval	Marquise	<
$\bigcirc$			Q	
Heart	Radiant	Step Cut	Emerald	-
	יי ו			
<ul> <li>High Ac</li> <li>1 min 2 sec</li> <li>Accuracion</li> <li>32 sec</li> <li>Optimu</li> <li>17 sec</li> <li>Quick:</li> <li>10 sec</li> <li>Manual:</li> <li>2 min 2 sec</li> </ul>	curacy: 800 cy: 400 m: 200 100	) contours ) contours ) contours ) contours 00 contours		
+ 1 min 30	sec			
▼ Scan &	Build			
Stone ID:				
	ad sc Jeck	,olde Offs	n p	
Advanced		-		

6. To perform shadow and reflect scanning sequentially, check Use Reflect.

Iternatively, you can perform shadow and reflect scanning separately: uncheck Use Reflect, then use the Shadow scan, then Pavilion Reflect Scan buttons separately.

- 7. Click Shadow & Reflect scan to start scanning. You may or may not be prompted to enter the Stone ID and Measured weight, depending on the settings (see Entering Stone ID and Measured Weight for more details). The following operations will proceed automatically:
  - a. As the shadow scan progresses, the shadow photos of the model in different orientations are taken and displayed on the screen, together with overlaid contours and a progress bar.



- **b.** After the shadow scan is completed, the model is built based on the scanned contours.
- c. The next step is pavilion reflect scanning. The stone is lighted from above and oriented so that a reflection from one particular facet may be observed. Then a few photos are made at slightly different orientations. This is done with each pavilion facet in turn. As the scanning progresses, new photos are displayed on the screen, together with the complete model (built from shadow contours) and a progress bar. The photos of the reflect scan are saved and can be reviewed later.



d. After the reflect scan is completed, the model is refined based on the reflection data. Both shadow and reflect models appear in the list (see Models management for more details on working with multiple models).

8. Save the model (optionally, together with the photosets).

Some post-scan operations may be initiated via the Scan & Build section. Switch between Basic and Advanced set of operations using the button at the bottom of the section. Operations are the same as for Shadow Scan (see the Post Scan Operations section there).

▼ Scan & Build	
Stone ID:	
Shadow scan	O Pump
Rotate to Door: First Facet	Selected Facet
Rx: 0,000° Rotate by 22,50°	÷ 🕹 👶
Print Save	Report
Pavilion Reflect Scan	
Rebuild Refine Pavilion	Refine Crown
Check Holder Offset	
Advanced 💌	

Some of the actions can also be set up to be performed automatically after scanning (see Automatic Actions).

## **Crown Scanning**

To run the reflect scanning of the crown, perform the following steps:

- Mount the stone in the Helium Crown Reflect scanner.
   Transfer the saved project to the computer controlling the Helium Crown Reflect scanner.
- 3. Start **HP Carbon** and open the project.



### A Notes

- Pay your attention to the absence of cutting type selection. Crown reflect scanning is solely intended to refine an existing model, and not to proceed from scratch.
  In your project, the current Main Scan will be used as the basis for lighting and building the improved model.

4. Click Crown Reflect scan to start scanning. The following operations will proceed automatically:

 $\boldsymbol{a}.$  A shadow photo is taken in order to determine the orientation of the stone.



**b.** A reflection photo of the table is taken to further adjust the orientation.



c. The stone is lighted from below at different angles so as to observe a reflection from each particular facet in turn. The photos of the crown reflect scan are saved and can be reviewed later.



() Crown reflect scanner is capable of highlighting the facets with slope < 40°.

d. After the crown reflect scan is completed, the model is refined based on the new reflection data. Now the list will contain a shadow model and two reflect models (see Models management for more details on working with multiple models).
 2. In case if the scanning failed to resolve edges between some nearly coplanar facets, or, conversely, produced some artificial edges, edit the model manually by adding or removing edges (see Model Adjustment for more details on the procedure).
 Some post-scan operations may be initiated via the Scan & Build section. Switch between Basic and Advanced set of operations using the button at the bottom of the section. The Crown Reflect scan shares available operations with the Shadow Scan (see the Post Scan Operations section there).

	Load model	
Stone ID: D-6	5084-001	
	Crown Reflect scan	
Print	Save	Report
	Capture background	1
Rebuild	Refine Pavilion	Refine Crown