Logitech Mouse G700 Setup

Setup of Logitech Wireless Gaming Mouse G700 for Digital Microscope

Connect and setup the mouse

• Unpack and check the package contents



Activate G700



• Connect the receiver. .



• Install Logitech Gaming Software from http://www.logitech.com/en-us/support



• Charge the mouse.



Create profile for Digital Microscope

• Start Logitech Gaming Software.



• Select Automatic Game Detection in the Home tab.



• Select Customize Buttons tab.



• Click Import/Export button (folder icon) and select Import... in the menu.



• Find DM-Logitech-G700-Custom-Profile.xml in DM installation folder and press "Open".



• In Profiles list there should be new DM profile, click it with right mouse button and select Properties.



• In Edit Profile window click Select Game Executable.

			- >
Logitech Gaming Softwa	Profiles	a Poli SaydloveS	
Commands	Edit Profile Itagefilove Sample		Scrol Right
Aperture Dec	Description: Digital Microscope		Right Click
Aperture Inc	Select Game Exocutable		Slart/Step Recording
Brightness Inc			
Left Click	SER DE SKTOPISTAGEMOVE SAMPLEISTAGEMOV	ESAMPLE.DXE	
Middle Click			ess Dec
Scroll Left	Lock profile while game is running		
Scrowinger		OK Cancel	
Drag commands onto buttons or prof			
	(i)	h) 🧭	* # ?
		_	

• Find DMClient.exe in DM application folder and click "Open".



Profile installed is finished. Now it will be activated on each start of DM application.