

Custom Report and Facet Marking

Facet Marking is introduced as a successor of the common facet type detection algorithm currently used in many report types (including Polish Reports).

Previously used algorithm only had a fixed set of pre-defined Facet Types which limited its use with certain fancy cuts and other diamonds with non-trivial shapes. For instance, limitations of the previous algorithm did not allow to properly mark all four groups of Pavilion Tier 2 Half Width in Cushion 0 model, marking Pavilion 2 Half 4 Width as Extra Additional. The new Facet Marking implementation allows the user to define as many Facet Group types as he requires, and all of the Facet Group properties are customizable. So, in the case of Cushion 0 example, the user now can create a new group named Pavilion 2 Half 4 Width and mark appropriate facets as belonging to this group.

Also, it is now possible to save a Sample file which contains both the Sample Model and a correct Facet Marking for the sample model. This marking from a Sample file can then be automatically translated to a Scan or Solution model to obtain correct marking and correct Custom Report.

This page describes general principles of how to work with the Facet Marking and Custom Report. As the Facet Marking is under constant improvement, some colors presented on the figures in this article may be out-of-date. You can find release 4.7.9 coloring description in the video:

Your browser does not support the HTML5 video element

On this page:

1

[Facet Marking for Standard Cuttings](#)

2

[Creating Samples with Facet Marking](#)

2.1

[Load Original Model](#)

2.2

[Open Custom Report Dialog](#)

2.3

[Edit Facet Marking](#)

2.3.1

[Option A: Select the incorrectly marked group and edit its properties](#)

2.3.2

[Option B: Create a new group and edit its options](#)

2.3.3

[Marking Specific Facets](#)

2.4

[Save Sample with Facet Marking](#)

3

[Using Sample files with facet Marking](#)

3.1

[Loading a Sample file into a Project](#)

3.2

[Applying Sample Facet Marking to Scans and Solutions](#)

4


[Creating Custom Report](#)

5

[Demo video of Custom Report and Facet Marking](#)

Facet Marking for Standard Cuttings

For standard cuttings, for allocation results, the facet marking is applied immediately after solution creation. The system uses the pre-installed sample markings specified for each standard cutting.




Using the specific marking sample for each cutting makes the resulting Facet Making more accurate and reduces or eliminates the need for manual corrections.

Creating Samples with Facet Marking


Load Original Model

First, you have to load a model which will become the Sample model. It is possible now to load DiamCalc DMC files in Oxygen using **File -> Open...** menu:




Open Custom Report Dialog

After loading the model, switch to **Diamonds** tab. The **Custom Report...** button will become available in the right panel:



Sample, described in this document, you can download here: [CUSHION0_sample_Custom_Report.dmc](#)


After pressing the **Custom Report...** button in the right panel, you will see the **Facet Marking** dialog:



Edit Facet Marking

When a model is opened in the Facet Marking dialog for the first time, it will only have Basic Marking, i.e. only basic Cut Elements will be marked, such as Table, Crown, Girdle, Pavilion, Culet.

You can now do all the marking manually, but it is much better to first apply **Auto Marking** using the button in the bottom-right. This will apply an algorithm which tries to automatically detect known Facet Types. This algorithm uses the existing Facet Type detection method used in Polish Reports. It is accurate most of the time for basic shapes, but it can make wrong assumptions about certain facet types for Fancy Shapes and scanned diamonds. Anyway, using Auto Marking will save you a lot of manual work by correctly identifying all or most facets:




In case of Cushion 0 Symmetric Model (created in Cut Designer), Auto Marking correctly detects all but Pavilion 2 Half 4 Width facet types, which are incorrectly marked as Extra Additional.

To fix this, you have two options:

Option A: Select the incorrectly marked group and edit its properties


To select a facet group, you can simple **Right Click** with your mouse on a facet belonging to this group. Alternatively, you can find the group in the list and select it manually.

To edit group properties, simply click on the property you want to change in the in the Group List in the right panel. A select box will appear with the available options:




For Cushion 0, we should set this group the following properties: Pavilion 2 Half 4 Width

The same method it is possible to set other facets in correct group:



Now we have a correct Facet Marking:



Option B: Create a new group and edit is options

To create a new group press the **New Group** button under the Groups List.

A new group will be created and placed in the end of the list. Select it to edit its properties.

Marking Specific Facets


To mark specific facets as belonging to a specific group, first select the group (in the Group List or by **Right Click**-ing on a facet which belongs to the desired group).

After selecting the group, **Left Click** on any facet that you want to assign to the selected group.

For quick "painting" of facets, you can hold the **Ctrl** key, press and hold the **Left Mouse Button** and then hover the mouse cursor over the facets you want to paint. Normally, this mode of operation is not required, but it can be helpful if you want to pain (mark) many facets at once, for instance when marking the Girdle.

Save Sample with Facet Marking

After you've finished editing the Marking, you can export a DMC sample file with embedded Facet Marking by pressing the **Export Sample** button in the bottom of the Facet Marking dialog:






Using Sample files with facet Marking

Loading a Sample file into a Project



To load DMC sample file into a project simply use the button from Samples tab in the Cutting&Method panel of the Scan tab.






Right now there's no indication telling whether a loaded Sample contains Facet Marking information, but the files that you have previously exported as Samples from the Facet Marking dialog, as described above, will have the Facet Marking data.

Applying Sample Facet Marking to Scans and Solutions

If you're working on a non-trivial cutting that requires Custom Report with specific Facet Marking or the stone proportions make it difficult for automatic facet detection algorithm to apply correct Facet Marking, you can apply a marking from a previously created Sample.


To do so, for the current project with already loaded model (for this document this is a sample - [Cushion0_scan.mmd](#)) in the Custom Report dialog press **From Sample...**



You will be presented with a Sample selection and Facet Marking preview dialog. In the dialog, press **Browse...** to specify a folder containing your marking Sample. This folder will be remembered the next time you open the dialog:



After the folder is selected, you will be presented with a list of DMC sample file names in the folder. Please note that the samples should contain Facet Marking data, otherwise they can not be applied. You can select desired samples from the list and preview the sample model and its Facet Marking as well as automatic transfer of marking to the current model:



While the input focus is in the Sample list, you can use **Arrow Up** , **Arrow Down** keyboard buttons to quickly scroll through the list and preview various sample markings.

If you would like to apply current marking and proceed with marking editing and Custom Report generation, press **Apply** . Otherwise, press **Discard** to get back to editing the the original marking you were working on.

If the model is significantly different from the Sample Model, the automatic Facet Marking translation may struggle to identify all of the facets that are introduced in the scanned model, especially if it's Blocking or Semi-Polished model and not a final Polish. In case there are any inconsistencies in the marking, the operator can fix them manually as described above.

Important Note


Sample Facet Marking is translated to current model only once — when the Custom Report dialog is first invoked for the current model. Once Custom Report dialog has been called for this particular model, the Facet Marking for this modelis preservedthe way the user left it. Whatever modifications are made in the Facet Marking dialog, will be preserved and stored in the OXG/OXGZ file when it is saved and subsequently loaded.

In coming versions we will introduce a method to (re-)apply Sample marking to current model at any given time.

Creating Custom Report

To create a Custom Report simply choose **Custom Report...** among the report options in the right panel. In the dialog, verify that the Facet Marking is correct, and fix it if necessary.

Finally, press **Make Report** button:



Once the document is generated, it will open in the Microsoft Word application.

Among other parameters and images, the document will have two additional tables: one with Statistics data (Min, Max, Avg, Dev) for each parameter of each Facet Group. and another one with individual parameter values of every facet in every Facet Group, i.e. specific angles, azimuths and heights of all the facets in every group:

Statistics table:

Parameter	Avg	Min	Max	Dev
Table Azimuth	88.97	88.97	88.97	0.00
Table Height (mm)	0.00	0.00	0.00	0.00
Table Height (%)	0.00	0.00	0.00	0.00
Crown Main Width Slope	31.67	31.45	31.90	0.45
Crown Main Width Azimuth	269.61	179.74	359.49	179.75
Crown Main Width Height (mm)	0.64	0.63	0.64	0.01
Crown Main Width Height (%)	0.11	0.11	0.11	0.00
Crown Main Length Slope	32.50	32.49	32.50	0.01
Crown Main Length Azimuth	180.90	90.63	271.17	180.54
Crown Main Length Height (mm)	0.64	0.63	0.66	0.03
Crown Main Length Height (%)	0.11	0.10	0.11	0.01
Crown Half Width Slope	39.35	38.38	40.48	2.10
Crown Half Width Azimuth	179.77	25.38	334.01	308.63
Crown Half Width Height (mm)	0.43	0.42	0.44	0.02
Crown Half Width Height (%)	0.07	0.07	0.07	0.00
Crown Half Length Slope	37.62	36.88	38.30	1.42
Crown Half Length Azimuth	180.22	58.92	300.00	241.08
Crown Half Length Height (mm)	0.43	0.42	0.43	0.02
Pavilion 2 Half Length Height (%)	0.23	0.22	0.24	0.02
Pavilion 2 Half 2 Width Slope	34.41	33.93	34.85	0.92
Pavilion 2 Half 2 Width Azimuth	181.18	35.49	329.99	294.51
Pavilion 2 Half 2 Width Height (mm)	1.46	1.44	1.47	0.03
Pavilion 2 Half 2 Width Height (%)	0.24	0.24	0.25	0.00
Pavilion 2 Half 2 Length Slope	30.72	29.75	31.42	1.67
Pavilion 2 Half 2 Length Azimuth	158.57	72.79	285.21	212.42
Pavilion 2 Half 2 Length Height (mm)	1.06	0.99	1.12	0.13
Pavilion 2 Half 2 Length Height (%)	0.18	0.16	0.19	0.02
Pavilion 2 Half 3 Width Slope	36.05	35.85	36.16	0.31
Pavilion 2 Half 3 Width Azimuth	179.62	19.73	340.77	321.04
Pavilion 2 Half 3 Width Height (mm)	1.42	1.37	1.44	0.07
Pavilion 2 Half 3 Width Height (%)	0.24	0.23	0.24	0.01
Pavilion 2 Half 4 Width Slope	36.77	36.45	37.09	0.64
Pavilion 2 Half 4 Width Azimuth	180.12	9.38	352.15	342.77
Pavilion 2 Half 4 Width Height (mm)	1.11	1.05	1.16	0.11
Pavilion 2 Half 4 Width Height (%)	0.18	0.18	0.19	0.02
Culet Slope	0.08	0.08	0.08	0.00
Culet Azimuth	249.67	249.67	249.67	0.00

Individual values table:

Pavilion 2 Half 2 Length Height (%)	0.17	0.16	0.18	0.19	0.18			
Pavilion 2 Half 3 Width Slope	36.12	36.16	35.85	36.07				
Pavilion 2 Half 3 Width Azimuth	19.73	161.49	196.48	340.77				
Pavilion 2 Half 3 Width Height (mm)	1.37	1.44	1.44	1.43				
Pavilion 2 Half 3 Width Height (%)	0.23	0.24	0.24	0.24				
Pavilion 2 Half 4 Width Slope	37.09	36.56	36.45	37.00				
Pavilion 2 Half 4 Width Azimuth	9.38	171.95	186.99	352.15				
Pavilion 2 Half 4 Width Height (mm)	1.05	1.14	1.16	1.07				
Pavilion 2 Half 4 Width Height (%)	0.18	0.19	0.19	0.18				
Culet Slope	0.08							
Culet Azimuth	249.67							
Culet Height (mm)	0.00							
Culet Height (%)	0.00							
Extra Knife Slope	59.83	60.84						
Extra Knife Azimuth	183.20	267.74						
Extra Knife Height (mm)	0.39	0.27						
Extra Knife Height (%)	0.06	0.05						
Extra Additional Slope	57.40							
Extra Additional Azimuth	174.11							
Extra Additional Height (mm)	0.78							
Extra Additional Height (%)	0.13							

In the tables above for a Cushion 0 Scan you can see values for the Pavilion 2 Half 4 Width group that we created earlier in the Sample Marking and which was automatically translated to the Scan model.

Demo video of Custom Report and Facet Marking

There is a demo video that illustrates the above points and works with Custom Report on Cushion sample:

Your browser does not support the HTML5 video element

